

# MINOLTA DUO-FIT FLASHGUN



Serial Nr.: no  
Minolta Code 8616

## Characteristics and Functions

The Minolta Duo-Fit Flashgun has a gray plastic body and can be used with bulb type AG bulbs. Very compact in size, it can also be easily used with Minolta 16 cameras. The front side is completely occupied by the metal dish. In the center is the seat where to insert the foot of the light bulb; on the lower side comes out the gray sync cable for connection with the camera. By removing the parabola, applying force to the left of the silver frame, the cable can be collected by making it roll up in its seat and fixing it in the appropriate central pin. The foot of the flash has the contact to use the hot shoe of the hot shoe. On the back there are the gray striped plastic button for ejecting the bulb used and the Guide

Numbers table for calculating the working diaphragm. The red test button is located on the top of the flash itself. Power is supplied by a 15v battery (Maxwell W10 type or equivalent). To access the battery compartment, you need to free the mount of the dish in the same way as for the collection of the synchro cable.

Weight 77g., Battery and lamp excluded.

Dimensions: width 80mm .; height 65mm .; depth 32mm.

Use AG-1 at 1/30 th					
ASA GN.	25	50	100	200	400
meter	18	22	36	45	72
feet	55	70	110	140	220

Open one f stop for Blue Bulb